


Stecker auf der CSM-Mutterplatine:
 H1 H3 H5 H7 H9 H11 H13 H15 H17
 H0 H2 H4 H6 H8 H10 H12 H14 H16



Stecker auf der CSM-Mutterplatine:
 H16 H14 H12 H10 H8 H6 H4 H2 H0
 H17 H15 H13 H11 H9 H7 H5 H3 H1

Definition der A- und C-Kammer gemäß TDR, S. 53

Mezzaninposition	Kartennummer	Kabeltyp	Kabelbeschriftung an beiden Enden	CSM-Platinensteckplatz
0		C - 1,33 m	0	H0
1		D - 1,33 m	1	H1
2		C - 1,33 m	2	H2
3		D - 1 m	3	H3
4		C - 1 m	4	H4
5		D - 1 m	5	H5
6		C - 0,67 m	6	H6
7		D - 0,67 m	7	H7
8		A - 0,67 m	8	H8
9		D - 0,67 m	9	H9
10		A - 0,67 m	10	H10
11		B - 0,5 m	11	H11
12		A - 0,67 m	12	H12
13		B - 0,67 m	13	H13
14		A - 0,67 m	14	H14
15		B - 0,67 m	15	H15
16		A - 1 m	16	H16
17		B - 1 m	17	H17